

# Byteon Firmware Settings Tutorial

2025/06

Byteon




# Part One

Performance Data Setting




# [Dashboard] -> click <a> ✓ open performance details</a>



#### Performance




# [Mining] -> Performance -> Preset -> Select the preset hashrate



Select the power-hashrate level, update from the rated hashrate.



## [Mining] -> Performance -> Preset -> Select the preset hashrate




Select the Preset data Save and Restart mining. Then the miner will

Then the miner will start outotuning.



# [Mining] -> Performance ->DIY Preset- Whole miner




If replaced the overclocking PSU,open it (3)

Disable 1 preset to change the voltage and frequency DIY 2 for whole miner.



# [Mining] -> Performance ->DIY Preset - Dashboard




If replaced the overclocking PSU,open it (3)

Disable 1 preset to change the voltage and frequency DIY 2 for whole miner.



# [Mining] -> Performance ->DIY Preset - Domain&Chips




If replaced the overclocking PSU,open it (3)

Disable 1 preset to change the voltage and frequency DIY 2 for whole miner.



# [Dashboard] -> Mining status




**Autotuning** 

Estimated to cost 2~3 hours




# [Dashboard] -> Mining status



Tuned, the miner will run the set hashrate



## [Mining] -> Performance -> Autoswitch presets



Autoswitch presets allows you to maintain optimal performance and stability of the device, minimizing the need for manual adjustments.




# Part Two

Other Operations




# [Mining] -> Advanced





# [System] -> General -> Backup and restore -> Rollback to stock



Backup settings


Restore settings

Reset

Rollback to stock




# [System] -> Security





# [System] -> Network






# Part Three

Review Miner Working Status



#### [Mining] - Performance Settings -> Boards information




#### Board view:

- ①Hashrate
- ②Errors
- (3)Sensors
- 4 Frequencies



# [Mining] -> Performance Settings -> Boards information










### [Mining] -> Performance -> Boards information -> Weak chips




Low chips - Orange

Bad chips - Red



# [Dashboard] -> Boards information -> Weak chips



Low chips - Orange

Bad chips - Red




# Part Four

Copy Logs and Diagnostic Report




# [Dashboard] -> Logs -> Status / Miner /Autotune / System



Copy the logs into .txt file



# [Dashboard] -> Tech report -> Diagnostic report






Diagnostic report








# [Firmware update]





# [Firmware update] -> Flash miner



the miner will restart and run updated firmware